AA1000TF Touch Free Dispense Water Boiler





Features

- On first install, place your hand in front of the sensor to start the process of self diagnosis, priming and boiling. Wait for 15 mins before starting to use
- Operating Functions:
 - » Switch Boiler on. Screen will light up Red "NOT READY, FILLING" as the Boiler goes trough self diagnosis checks
 - » Once Boiler is primed with water, the boiler will begin to heat. Screen reads "NOT READY, HEATING"
 - $\, \text{ \sc w}$ When correct temperature is reached the screen display will change from Red to White and will read "READY"
 - » The Boiler will continue to continue in a heat/fill cycle until the tank is at full capacity
- To dispense water, place your hand in front of the sensor and then place a cup in the cup recess area. This will break a safety beam which allows dispensing. Whenever boiler is dispensing a safety warning light will flash "CAUTION BOILING"

Specifications

- Rapid draw off: 10ltr, 60 cups above 96°C
- Hourly capacity: 31ltr, 186 cups above 96 C
- Tap clearance 135mm
- Premium grade Stainless Steel
- High insulation to prevent heat loss
- Low voltage switching
- Desgined to operate with mains pressure between 2-7 bar

Description	Dimensions H X W X D (MM)	Weight (Kg)
Table Top	545 X 240 X 522	12.3



refreshingly different